

# -32°C Blast Freezer BFR 2200 series



### -32°C Blast Freezer BFR 2200 Series :-

-32°C Blast Freezer BFR 2200 series is single-temperature type freezers with intelligent digital temperature control panel and Embraco/ Tecumseh compressors. The temperature range of these freezers is +30°C to -32°C. The main purpose of blast freezers is to rapidly bring down the temperature of foodstuffs or fresh produce, freezing them very quickly

### Features :-

- ◆ R404A is the refrigerant which is free from CFC and foam
- ◆ Provided with core temperature probe which will pick out easily from food
- ◆ Single self-closing door is fitted with a full-height handle and removable magnetic gasket for more convenience
- ◆ Auto defrost system
- ◆ The interior and exterior material is made up of SUS 304 stainless steel
- ◆ Fan cooling system
- ◆ Gastro norm GN 1/1 pans – 60\*40cm bakery pans are provided
- ◆ The height of the equipment can be adjusted to meet the various height requirements
- ◆ Temperature in the cabinet drops from normal temperature +40 °C in just 30 min

### Applications:-

Used for cooling food quickly and for prevention of surface freezing and also preserve the nutritional values of food items. Mostly used in frozen food industries like iced cream, pre- prepared meals and vegetables or fish.

## -32°C Blast Freezer BFR 2200 series

### Specification:-

Model No.	BFR 2200	BFR 2201
Net Capacity	90L	188L
No. of Shelves	5	10
Temperature Range	+30 °C to - 32 °C	+30 °C to - 32 °C
Dimensions	725×795×865 mm	725×795×1400 mm
Power	698W	1050W
Net Weight	70kg	135kg
Power Supply	220V/50Hz 110V/60Hz	220V/50Hz 110V/60Hz